

Model: EDM2* System


This installation instruction is applicable to LED outdoor windowsill lights.

Installation Precautions:

1. Please read through the instructions before installation.
2. The product should be installed by a professional electrician.
3. Make sure the power supply is cut off before installation and maintenance, to avoid the risk of electric shock.
4. Before installing the lighting fixtures, please confirm that the installation surface is firm and reliable to avoid loosening or detachment of the lighting fixtures.
5. Keep the instruction manual for reference only.

Surface mount:

1. As shown in Figure ①, the installation groove position (dashed box), the groove size is $L * M = (80-100) * (30-40)$, and the excavation depth is $\geq 30\text{mm}$.
2. Connect the wires according to the label instructions on the input line as shown in Figure 2. Waterproof the wire connections and plug all wires into the slots to avoid installation interference.
3. Fix the lighting fixture with 2 screws (provided by the customer), as shown in the figure ③
4. The installation of the lighting fixtures is completed, as shown in Figure ④



Notes :

- 1. If the glass protective cover is found to be damaged during installation, it must be replaced, and the lamp can only be used with a complete protective cover.**
- 2. When the glass protective cover is damaged and replaced, customers can only use the glass protective cover provided by our company.**
- 3. If the external flexible cable or cord of this lamp is damaged, the cable should be replaced by the manufacturer or its service agent or a similarly qualified person to avoid danger**